


passend für / to fit

MERCEDES BENZ

BM 903 / 904 (Sprinter) (1995 →)



Quality Made For The World

	VL	VR	H
308 D	10 13 0028	10 13 0028	10 13 0083
308 CDI	10 13 0028	10 13 0028	10 13 0083
310 D	10 13 0029	10 13 0029	10 13 0083
311 CDI	10 13 0028	10 13 0028	10 13 0083
312 D	10 13 0029	10 13 0029	10 13 0083
313 CDI	10 13 0028	10 13 0028	10 13 0083
314	10 13 0028	10 13 0028	10 13 0083
408 D	10 13 0028	10 13 0028	10 13 0083
408 CDI	10 13 0028	10 13 0028	10 13 0083
410 D	10 13 0029	10 13 0029	10 13 0083
411 CDI	10 13 0028	10 13 0028	10 13 0083
412 D	10 13 0029	10 13 0029	10 13 0083
411 CDI	10 13 0028	10 13 0028	10 13 0083
414	10 13 0028	10 13 0028	10 13 0083

